

BASIC TELEPHONE FEATURES

Turn Handset on



Turn Handset off



Make a call




Answer a call



End a call




Last number redial



DIRECTORY DIALING




DIRECTORY NUMBER STORING




BASIC TELEPHONE FEATURES


Low battery



Ringer off



Ringer on



Volume up



Volume down



Fold

TO USE THE C4010 Ex SAFELY

Never take the C4010 Ex out of the carry case in an explosive atmosphere

Never use accessories
For example, do not use the belt clip

Never charge the battery in an explosive atmosphere

Never use another type battery

Never use in mining environments

A0801670

C4010 Ex Quick Reference Card



Important: Only use the handset in the carry case.
Only charge the handset in designated areas.

For additional information on the operation of your handset, consult the C4010/4020 User Guide